



Please refer to the numbered drawings which correspond to the paragraph numbers of the instruction manual.

The reference language for these instructions is French.

GB

09/2021

Contents

Introduction	1	Fault finding	5
Installation	1	Maintenance	6
Use, safety	3	Conformity with regulations	7
Cleaning, hygiene	4		

Introduction

The User Manual contains useful information for the user on how to work correctly and in complete safety, and is designed to make it easier to use the machine (called «machine» or «appliance» below).

What follows is in no case intended to be a long list of warnings and constraints, but rather a series of instructions meant to improve the service provided by the machine in every respect, and particularly to avoid a series of injuries or damage to equipment that might result from inappropriate procedures for use and management.

It is essential that all the people responsible for transporting, installing, commissioning, using, maintaining, repairing or dismantling the machine should consult this manual and read it carefully before proceeding with the various operations, in order to avoid any incorrect or inappropriate handling that might be result in damage to the machine or put people's safety at risk.

It is just as important that the Manual should always be available to the operator and it should be kept carefully where the machine is used ready for easy and immediate consultation in case of any doubt, or in any case, whenever the need arises.

If after reading the Manual, there are still any doubts concerning how to use the machine, please do not hesitate to contact the Manufacturer or approved After Sales Service provider, who is constantly available to ensure quick and careful service for improved machine operation and optimum efficiency.

Note that the safety, hygiene and environmental protection standards currently applicable in the country where the machine is installed must always be applied during all phases of machine operation. Consequently it is the user's responsibility to ensure that the machine is operated and used solely under the optimum safety conditions laid down for people, animals and property.

Introduction

1.1 DESCRIPTION

• The 25 kg angled peeler is used in vegetable preparations (in restaurants, catering kitchens and small industries) for peeling potatoes, carrots, turnips, salsifies, celery, etc.



1.1

- A** Rear electric housing
- B** Hinged transparent lid
- C** Control support rail
- D** Stainless steel cylinder

- E** Stainless steel angled table
- F** Adjustable feet
- G** Collection tub
- H** Removable filter basket
- I** Vegetable evacuation spout
- J** Hinged handles and door
- K** Water inlet

Installation



ATTENTION!!

Machine storage: -25°C to +50°C

Ambient temperature during operation: +4°C to +40°C

This machine is for professional use and must be used by staff trained to use, clean and maintain it, in terms of reliability and safety. Use the machine in adequately lit premises (See applicable technical standard for the country of use. In Europe, refer to standard EN 12464-1)

When handling the machine, always check that the parts taken hold of are not mobile elements: risk of dropping and injury to the lower limbs.

The machine is not designed for use in explosive atmospheres.

2.1 DIMENSIONS - WEIGHT (for information only) 2.1

- Gross weight when packaged : 112 kg
- Net weight : 90 kg

- Dimensions of packaging (L x W x H) :930 x 600 x1580 mm
- Overall dimensions : 880 x 565 x 1425 mm


2.2 LOCATION

- Handling - Transport


The machine is packaged in such a way as to be lifted with a fork-lift truck. In the event of manual handling of the machine alone, two persons will be required.

- This peeler requires:
 - A connection to the cold water supply (see §2.3).
 - An adequate outlet to the drain (see § 2.4).
 - An electrical power supply (see § 2.5).
- This peeler must be mounted on its angled table.
- Leave enough space above the machine so that the lid may

be raised, and in front of the table so that the filter basket may be removed.


- If necessary, block and level the table by unscrewing the lock screw of the adjustable feet (13 mm socket spanner)  **2.2**
- Adjust the foot then lock in position.
- Check that the machine is stable.
- We recommend anchoring the table in position to avoid any risk of it tipping when loaded, by counter drilling the attachment holes of the feet (8 mm dia. screws max. x 40 mm long and rawl plugs not supplied).

2.3 CONNECTION TO THE WATER MAINS SYSTEM

- This peeler uses the pressure of the water mains supply and a reduced flow rate (approximately 7 litres per minute).
- In conformity with the sanitary regulations, the water inlet and its stop tap are situated above the top overflow level, at a standardised distance (overflow device).  **2.3a**

Note: As a precaution, a stop tap may be fitted on the wall.

- Connect to the water supply by means of a flexible, reinforced hose of 15 mm diameter, which can withstand the pressure of the water supply and is sufficiently long enough.
- Carefully connect the hose with two Jubilee clips.

Note: An electrovalve may be supplied as an option (ask us for details).  **2.3b**

2.4 EVACUATION OF USED WATER AND SEPARATION OF THE WASTE

- The waste must be separated due to its size (peelings, starch, moss, soil, etc.).
- Some installations have starch decantation tanks that may be directly connected. For other installations, this peeler is supplied as standard on a filter table in order to avoid blockages and bad smells.
- To connect the machine to the drain, attach the hose (internal dia. 50 of mm) to the used water tank with its collar (may be swivelled through 360 °).

• Tips:

To evacuate the used water correctly, avoid:

- vertical drops onto inspection chambers (formation of foam),
- sharp angles,
- flattened, deformed or narrow pipes,
- counter slopes, or slopes which are not steep enough.

2.5 ELECTRICAL CONNECTION



ATTENTION!!

Connection to the electrical power supply must be done according to proper professional practice by a qualified and authorised person (see current standards and legislation in the country of installation).

If an adapter is used on the socket, a check must be made that the electrical characteristics of this adapter are not lower than those of the machine.

Do not use multiple plugs

The AC power supply to the machine must comply with the following conditions;

- Maximum voltage variation: $\pm 5\%$
- Maximum frequency variation: $\pm 1\%$ on a continuous basis, $\pm 2\%$ over short periods

ATTENTION: the electrical installation must comply (for design, creation and maintenance) with the legal and standard requirements in the country where used.

- Check that the electric mains voltage, the value shown on the specification plate.
- The machine's electrical power supply must be protected against voltage surges (short-circuits and excess voltages) by using fuses or thermal relays of the appropriate gauge relative to the place of installation and machine specifications.

ATTENTION: Concerning protection against indirect contact (depending on the type of power supply provided and connection of the exposed conductive parts to the equipotential protection circuit), refer to point 6.3.3 of EN 60204-1 (IEC 60204-1) with the use of protection devices for automatic shut-off of power in the event of an insulation fault with a TN or TT, system, or for the IT system, with the use of a permanent insulation or differentials controller for automatic shut-off. The requirements of IEC 60364-4-41, 413.1 must apply for this protection.

For example: in a TT system, a differential circuit breaker must be installed upline of the power supply, with a suitable power cut-off (e.g.: 30 mA) on the earthing installation for the place where it is planned to install the machine.

ATTENTION: Failure to comply with these instructions means the customer runs the risk of machine failure and/or accidents due to direct or indirect contacts.

- Check that the voltage of the electrical system is the same as that marked on the rating plate.
- The machine must be protected by a differential circuit breaker and a 16 A fuse per phase (see table).
- The socket must be accessible so that the machine can be easily unplugged before any work is carried out on it.

Motor characteristics:  **2.5a**




- B** Number of phases (1 single phase - 3 three phase)
- C** Nominal voltage in Volts (value, range or commutation)
- D** Frequency (Hertz)
- E** Nominal power (Watts)
- F** Nominal current (Amperes)
- G** Rating of fuse protecting electrical line (Amperes)
- H** Approximate electrical consumption (KWh)


1) Dual voltage three phase motor

- Provide a single phase wall socket with 3 phases + earth, rating 20A and a matching watertight plug fitted on the power supply cable.



The machine must be earthed with a green / yellow wire.

- Check the direction of rotation of the plate fitted to the machine.
 - Press the START button (see § 3.1).
 - Visually check the rotation of the plate via the transparent lid. It should be turning in an anti-clockwise direction  (see arrow on the plate hub or on the top right of the cylinder).
- If the direction of rotation is reversed, change over the two phase wires on the plug.
 - The initial connection is made for a higher voltage:
 -  (e.g. 400 V) For lower voltage supplies.
 -  (e.g. 230 V) proceed as follows:
 - Disconnect the machine.

- Refer to the wiring diagram in §6.6.
- Remove the plate.
- Turn the machine over or lie it down.
- Remove the foot assembly by unscrewing the 4 outer screws.
- Change over the terminal board connecting strips.
- Change the integral plate wire by moving the connection terminal lug marked as upper voltage P2 (400V) onto that for the lower voltage P1 (230V).
- Refit the foot assembly.
- Check anti-clockwise rotation .



The machine must be earthed.

2) 230V power supply for external controls

The machine is fitted with a 230 volt AC power supply of a maximum of 2 Amps controlled by the control box, for possible connection of a solenoid valve.

To PAT test the Electrolux Range of Food Preparation Equipment, the PCB board needs to be disconnected before any test is done. This is due to the fact that the boards are fitted with a grounding diode that can give incorrect result during such a test. Also on a standard appliance a flash test of 25 amps and up to 3000v is used but, as you would expect, to use this on equipment, which has a printed circuit board would be quite destructive to that board. We would recommend the use of a PAT tester approved for computer systems which use a lower rate of amps.

The appliance is perfectly safe and is CE certificated. There are two ways to get over come this problem.

- Disconnect the board as instructed and test using test for PC's,
- Or install the mixer on a fused spur (no plug) as this takes it away from being a portable appliance and the PAT test is then not needed.

Use, safety



ATTENTION !!

Clean the machine properly prior to its first use

This machine is for professional use and must be used by staff trained to use, clean and maintain it, in terms of reliability and safety.

Use the machine in adequately lit premises (See applicable technical standard for the country of use. In Europe, refer to standard EN 12464-1)

When handling the machine, always check that the parts taken hold of are not mobile elements: risk of dropping and injury to the lower limbs.

Uncontrolled closure of the lid involves a risk of crushing the fingers.



It is strictly forbidden to put the safety systems out of action or modify them: Risk of permanent injury!!!!

Check that the safety devices operate correctly each time before using (see paragraph 3.1).

Never put a hand, a hard or frozen object in the appliance is on.

For health and safety reasons, always use a washable or disposable strong head covering that covers the hair completely.

The machine is not designed for use in explosive atmospheres.



Any other use than that described in this manual will not be considered normal by the manufacturer.

3.1 OPERATION - SAFETY

- The safety of the user is ensured by:
 - A continuous pressure control system to evacuate the vegetables when the door is opened.
 - The motor stopping when the lid is opened.
 - The START button needing to be pressed after stoppage ("no voltage" release).
 - The size and design of the waste outlet zone, which avoids any blockage.
 - The angle of the machine, making vegetables and waste easier to remove.

- Respecting the instructions of this manual for the use, cleaning and maintenance of the machine.

• Control housing

A,B,E Timer

C STOP button

D START button

- This peeler operates normally if:

- The door and lid are closed.
- The timer is set to the continuous or timed position.

a) Continuous operation

- 1/ Press and hold key **A** until — is shown on **E**.
- 2/ Start by pressing key **D**.
- 3/ Stop by pressing key **C**.

b) Timed operation:

- 1/ Press key **A** or **B** to select the time on **E**.
- 2/ Start by pressing key **D**.

*Note:- To change the time while the timer is running, press key **C** then change the setting using key **A** or **B**, resume the cycle by pressing key **D**.*

- The time selected at the beginning of the cycle remains in the memory.
- To stop the current cycle permanently, press key **C** twice.

c) Operation by holding the START button in :

- When the door is opened to remove the products.

d) Stopping :

- Press the STOP button **C** then, open the door or the cover.


3.2 NOMINAL CAPACITIES

- Per operation: bags of 25 kg.
- Hourly output (for information only):
 - peeling of potatoes: 400 kg.

Note: The performances vary depending on the nature, shape, size and condition of the products to be peeled, as well as the results desired.

3.3 PROCEDURE FOR PEELING

• Loading

- Open the lid.  3.3
- Check that the door is locked and the filter basket is in position.
- Load the products and close the lid.

Note: The products must not be loaded above the front edge of the cylinder.



Do not overload - Do not pack the products in. Overloading will damage the quality and speed of the work.

- Open the water stop cock partially to suit the work to be performed and check that the flow rate is sufficient.
- Select the cycle time (see § 3.1) and press the START button.
- At the end of the cycle, the machine will stop automatically.

Note: If the peeler has an electrovalve fitted, the water system opens and closes automatically at the start and end of the cycle.

• Unloading


- Place a tray under the outlet chute.
- Close the water inlet stop cock.
- Unlock the door with one hand and press the START button with the other.
- Open the door completely, ensuring that the vegetables are channelled out.
- Close the door and programme the next cycle (see § 3.1).

Note: Monitor the peeling carefully when the timer is in the continuous operation position.



Do not forget to empty the filter basket when it is full or after peeling.

3.4 USE OF EQUIPMENT

- Open the lid.
- Hold the plate by the handle **B** and lower it slightly inclined, deflector side, until the hub engages on the drive shaft.
- Turn the plate until the drive pin drops into its housing. This should drop in by its own weight.  5.3

Note : Ensure that sufficient space is available above the machine so that the lid may be opened, and in front of the stand so that the basket may be removed.

Note : If the equipment does not fit into place correctly, do not force it, remove it and clean the shaft and hub (see § 5.3).

3.5 RECOMMENDATIONS FOR USE

• To peel vegetables:

- The vegetables do not need to be washed before peeling.
- Avoid peeling small quantities.
- Peel vegetables of the same thickness.
- Cut long vegetables (salsifys), tips, tops of carrots.

- Peeling times: 1 to 2 minutes for new vegetables (potatoes, carrots), 2 to 4 minutes for the rest.



Do not use the abrasive plate to scrape shellfish.

Cleaning, hygiene

Routine Maintenance

The owner and/or user of the appliance are responsible for the following maintenance tasks.



IMPORTANT

Any problems resulting from improper maintenance or lack of maintenance as described below will void the terms of the warranty.



WARNING

Always power off the unit before cleaning or maintenance.


- It is prohibited to remove any safety devices.
- Use appropriate personal protective equipment.
- Never jet-wash, pressure-clean, or steam-clean the appliance.



Cleaning the Appliance

- Clean the appliance and accessories before first use.
- **To make it easier to clean the unit, systematically clean the appliance and accessories as soon as you finish working with them.**
- Clean removable parts with hot water and detergent/degreasing agent/disinfectant compatible with the unit's materials: use neutral soaps or biodegradable products (to reduce the emission of pollutants into the atmosphere).
- Rinse with clean water and allow to dry (or wipe with a soft cloth).
- Do not use metal equipment or scouring sponges (e.g. Scotch Brite) to clean the appliance.

- Do not use abrasive detergents as they will scratch the surfaces.
- Do not use solvent products (e.g. trichlorethylene).


 **The use of chlorinated products, and in particular those containing didecyldimethylammonium chloride (CAS 7173-51-5), is strongly discouraged.**

If, however, a specific cleaning procedure requires the use of such products, carefully respect the dosages and instructions recommended by the manufacturer.

Rinse surfaces thoroughly with clean water and then dry.

Misuse (overdosage, inadequate rinsing) can cause irreversible damage to the surfaces (including aluminum and stainless steel).

4.1 AFTER USE

- Close the lid and open the water stop cock as far as possible.
- Operate the peeler for a few seconds to get rid of the remaining waste and to rinse the inside of the machine.
- The filter basket must be emptied then cleaned under running water along with the tray.
- Clean the outside of the machine with a damp sponge.
- Leave the door ajar in order to ventilate the peeling chamber and avoid squashing the seal.  **4**

Fault finding

5.1 THE MACHINE WILL NOT START, CHECK THAT:

- The machine is plugged in.
 - The electrical power supply to the socket is correct.
 - The door and lid are closed.
 - The timer set on continuous or timed operation. 3.1
- If the problem persists, contact the maintenance department of your dealer.

5.2 ABNORMAL NOISES

- Stop the machine.
- Check that the rotating parts are fitted correctly.
- Verify that there are no stones or foreign bodies in the peeling chamber (risk of jamming and damaging the plate and the abrasive part of the cylinder).
- If the noise persists and the machine lacks power, check that:
 - the three phase motor is not operating on two phases,
 - the belt is not worn (see § 6.1),
 - the plate turns freely by hand.

5.3 IF THE PLATE JAMS ON THE SHAFT 5.3

- Unplug the machine.
- Open the lid.
- Remove the central screw **A** from the plate with a 13 mm spanner.
- Remove the handle **B**.
- Insert the screw **A** again to lift the plate.
- Tighten the screw in completely.
- Remove the plate.

Note: Clean and lubricate the drive shaft of the machine regularly with tallow or food grease.

5.4 QUALITY OF THE PEELING

- Inadequate, irregular peeling with flats may be caused by:
 - Incorrect connection (machine rotating in the opposite direction, see § 2.5.1).
 - Peeling time too short.
 - Overloading of products (see § 3.3).
 - A worn or clogged abrasive plate (see § 6.2).
 - Worn abrasive part of the cylinder.
 - Vegetables which are too long, of different sizes or too soft.



If the problem persists, contact the maintenance department of your dealer.





ATTENTION!!

Unplug the machine before carrying out any operation.

All access to the electrical parts requires the use of a tool.

Maintenance may only be carried out by a qualified, trained and authorised person.

6.1 MECHANISM

- This peeler only requires a minimum amount of maintenance (the bearings of the motor and mechanism are greased for life).
- It is recommended that the following be checked at least once a year:
 - the electrical connections.
 - the condition of the flexible water inlet hose and its attachment.
 - the wear of the belt.
- **Tensioning the belt:**  **6.1**
 - Unplug the machine.
 - Remove the peeler from the table (4 screws, 13 mm hex. spanner).
 - Turn the machine over or lie it down.
 - Bring the tensioning screw **B** until it touches the support bracket, then tighten by 3 turns with a spanner.
 - Tighten the motor retention screws **B** in position.
 - Check that the belt is tensioned correctly by pressing on one side of the belt with your index finger.
 - Fit the ventilation plate and the peeler on its table.
 - Check that the peeler operates correctly.
- Unscrew by one turn the 3 screws **A** retaining the motor (13 mm hex. spanner).
- Remove the ventilation plate.
- Tension the belt (with the tensioning screw **B**, 13 mm hex. spanner).
- **Changing the belt:**  **6.1**
 - Completely remove the 3 screws **A** retaining the motor.
 - Remove the support bracket and remove the belt.
 - Fit a new belt, ensuring that it is correctly aligned in the grooves.
 - Fit the support bracket but do not tighten the screws.
- Access to electrical components.
 - Unplug the machine.



Residual voltage at the capacitor terminals.

- The capacitors may retain an electrical charge. To avoid taking any risks when carrying out work, we recommend discharging them by connecting their terminals with an insulated conductor (e.g. a screwdriver).

6.2 MAINTENANCE OF THE EQUIPMENT

- **ABRASIVE PLATE:** Inefficient
 - Worn abrasive layer which has revealed the base of the plate (poor peeling of the vegetables and formation of flats): change the plate.
 - Clogged plate (calcium, starch or soil deposits): brush the plate. To remove it, see § 5.3.
 - Worn abrasive part of the cylinder: replace it.

6.3 ADJUSTING THE SAFETY DEVICES

- Check that the safety devices are operating correctly on a regular basis:

The motor should stop:

 - When the lid is opened.
 - When the door is opened.
- If either of these two functions does not operate correctly:
 - Do not use the machine.
 - Have it adjusted by the maintenance of your dealer.

6.4 CHANGING THE SEAL AND ADJUSTING THE DOOR

- Proceed as follows:
 - Pivot the door upwards.
 - Remove the old seal, and carefully scrape and clean its groove.
 - Apply a thin bead of silicon sealant in the groove.
- Fit the seal in the groove, ensuring that the joint is in the middle at the top.
- Finish off by applying a second bead of silicon, ensuring that you do not apply too much.



Leave to dry for 24 hours in the ambient air, leaving the door closed before use.

6.5 CHANGING THE LID SEAL

- Proceed as follows:
 - Remove the old seal and clean the lid.
 - Apply a bead of silicon sealant in the seal groove.
- Fit the seal in the groove, ensuring that the joint is in the middle at the back of the lid.



Leave to dry for 24 hours in ambient air, with the lid unlocked.

6.6 ELECTRICAL COMPONENTS

See electrical diagrams.

• Identification of the colours of the wires:

- Power circuit : black
- Control circuit : red
- Phases : L1 /L2 / L3
- Neutral : N
- Earth : B/C green and yellow

• Identification of the components:

- S1 : Lid safety device
- S2 : Door safety device
- S3 : Motor probe
- M : Motor
- Mi : Timer
- Y1 : Electrovalve

6.7 ADDRESS FOR SERVICE REQUIREMENTS

We advise you to contact the dealer who sold you the machine.
For any information or orders for spare parts, specify the type of machine, its serial number and the electrical characteristics.



The manufacturer reserves the right to modify and make improvements to the products without giving prior warning.

Dealer's stamp


Date of purchase :

Conformity with regulations

The machine has been designed and manufactured in conformity with :

- The machine directive 2006/42 EEC,
- The CEM directive 2014 / 30 EU,
- 2011/65/EU Directive on the restriction of the use of certain hazardous substances

2002/96/CEE « WEEE »

The symbol «  » on the product indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact the sales agent or dealer for your product, your after-sales service, or the appropriate waste disposal service.

2006/12/CEE "Waste"

The machine is designed so that it does not contribute, or as little as possible, to increasing the quantity or harmfulness of the waste and the risks of pollution.

Make sure to observe the recycling conditions.

94/62/CEE "Packaging and packaging waste"

The packaging for the machine is designed so that it does not contribute, or as little as possible to increasing the quantity or harmfulness of the waste and the risks of pollution.

Make sure to eliminate the various parts of the packaging in appropriate recycling centres.

- To the European standards :

- EN 60 204-1-2006 electrical equipment of machines,
- EN 13208-2000: Vegetable-peeling machines, hygiene and safety.

This conformity is certified by:

- The CE conformity mark, attached to the machine.
- The corresponding CE declaration of conformity, associated with the warranty.
- This instruction manual, which must be given to the operator.

Acoustic characteristics:

- The acoustic pressure level measured in accordance with the test code EN ISO 3743.1-EN ISO 3744 (73 dBA).

Protection indices as per the EN 60529-2000 standard:

- IP55 electrical controls.
- IP34 overall machine.

Integrated safety devices

- The machine has been designed and manufactured in compliance with the relevant standards and regulations, mentioned above.
- Before using the machine, the operator must be trained to use the machine and informed of any possible residual risks (personnel training obligation)

Food hygiene:

The machine is made from materials that conform to the following regulations and standards:

- 1935/2004 EEC materials and objects in contact with foodstuffs
- EN 601-2004: cast aluminium objects in contact with foodstuffs

The surfaces of the food area (excluding the abrasive parts) are smooth and easy to clean. Use detergents that are approved for food hygiene and respect the instructions for their use.