



**Gentle on you**  
gentle on your  
dishes

**Accessories & Consumables**  
To make our customers'  
work-life easier and more  
profitable

Make your work simple and your equipment last longer with original Accessories&Consumables. To guarantee the best performance and boosting the highest profitability.

## Gentle on you gentle on your dishes

No matter what you put in your dishwasher, from the targets, dirties pans to your most delicate glassware, our Electrolux Professional detergent combined with our Electrolux Professional baskets, you will get outstanding cleaning and sparkling results any time.

### Excellent washing & rinsing, savings and efficiency

Optimize your operations with baskets for all needs! The shape of the spray nozzles and the rotating arms of the wash chamber, combined with the rinse booster pump and our detergent, ensure excellent washing and rinsing. Our baskets are designed to get water distribution evenly throughout the area of the washing basket, leaving no area uncovered.



**0S2093**  
C13 Eco  
Detergent  
for Dishwasher



**0S2095**  
C14 Rinse  
Aid Plus  
for Dishwasher



**048795**  
Yellow basket  
500x500 mm  
for 18 plates



**048965**  
Blue basket  
500x500 mm  
with 16 containers  
for cutlery



**048968**  
Blue basket  
500x500 mm  
with tilted bottom  
for 16 glasses

To find out more, visit us at  
[www.electroluxprofessional.com/customer-care/](http://www.electroluxprofessional.com/customer-care/)

