



The image shows a close-up of the Electrolux C40 Degreaser, a stainless steel industrial machine. It features a control panel with two blue rotary knobs and a black push-button. Below the panel is a perforated metal tray. The machine is part of a larger kitchen equipment setup, with a griddle and other components visible in the background.

C40 Degreaser for hot surfaces at high temperatures

Accessories & Consumables
To make our customers'
work-life easier and more
profitable

Make your work simple and your equipment last longer with original Accessories&Consumables. To guarantee the best performance and boosting the highest profitability.

C40 Degreaser for hot surfaces

The ideal cleaning solution for cooking surfaces at high temperatures.

Recommended for fry tops, braising pans and multifunctional cookers.

Total food safety.

Ideal for intermediate cleaning and quickly when preparing different types of food i.e. fish, meat and vegetables.

- ▶ Quick cleaning without needing to first cool down the equipment
- ▶ Thorough removal of stubborn food residues
- ▶ Also available as **complete cleaning kit**



Code	Description
0S1841	C40 Degreaser for hot surfaces 1 pack of 6x1 liter bottle
0S1379	Cleaner brush with handle for hot surfaces
0S1377	Squeegee with handle for hot surfaces
055995	Scraper for smooth cooking plate



Follow the cleaning path with
Electrolux Professional

To find out more, visit us at
www.electroluxprofessional.com/customer-care/

