

# Upute za uporabu sušilice rublja myPRO<sup>XL</sup>

## Kontrolni panel



## Upute

- 1**  Otvorite vrata i napunite uređaj
- 2**  Odaberite program
- 3**  (ako je primjenjivo, ubacite kovanicu ili žeton)  
Pritisnite tipku ► Start za pokretanje programa
- 4**  Sušenje je završeno kad se oglasi zvučni signal

## Programi

-  Visoka temp.\* 60 °C  
Najbolji za higijenske cikluse
-  Srednja temp. 40 °C
-  Niska temp. 20 °C
-  Bez grijanja