



WT 38 USPH spare parts list (pag1/2)



- A1= controller
- C1= wash pump remote control switch
- D1÷D3= auxiliary relay
- E1= water load electric valve
- M1= wash pump
- M3= rinse pump
- M4= drain pump
- M6= detergent dispenser
- M7= rinse aid dispenser
- NT2=ntc boiler temperature
- R1= tub heating element
- R2= boiler heating element
- T3= transformer

DOC. NO. 599669101
DATA : 07.2002

WT 38 USPH spare parts list (pag2/2)

