

Spare Parts List

NO	DESCRIPTION	Serial #	QTY	COMPONENT PNC	Model Number	Model PNC
1	lid	ALL	1	0USD91	KCCF140WH	738230
2	sealing strip - gasket	ALL	1	0USD48	KCCF140WH	738230
3	hinge top cover	<913***	3	0USL85	KCCF140WH	738230
		≥ 913***	3	0USL87	KCCF140WH	738230
4	hinge down cover	<913***	3	0USL86	KCCF140WH	738230
		≥ 913***	3	0USL88	KCCF140WH	738230
5	thermometer bracket	ALL	2	0USC8A	KCCF140WH	738230
6	NSF thermometer	ALL	1	0USD49	KCCF140WH	738230
7	lock hook	ALL	1	0USD50	KCCF140WH	738230
8	hinge	<913***	3	0USD51	KCCF140WH	738230
		≥ 913***	3	0USL89	KCCF140WH	738230
9	basket	ALL	1	0USD52	KCCF140WH	738230
10	cabinet	ALL	1	N/A	KCCF140WH	738230
11	cooling unit rear cover	ALL	1	0USDAB	KCCF140WH	738230
12	compressor	ALL	1	0USD53	KCCF140WH	738230
12a	Relay	ALL	1	0USC8P	KCCF140WH	738230
12b	Overload	ALL	1	0USC8V	KCCF140WH	738230
12c	Run Capacitor	ALL	1	0USC8Z	KCCF140WH	738230
13	compressor cover	ALL	1	0USL84	KCCF140WH	738230
13a	plug seat	ALL	1	0USDH6	KCCF140WH	738230
14	power cord	ALL	1	0USD54	KCCF140WH	738230
15	copper tubing	< 005222000182	1	0USC8J	KCCF140WH	738230
		≥ 005222000182	1	0USO63	KCCF140WH	738230
16	drying filter	ALL	1	0USD55	KCCF140WH	738230
17	double orifice press block	ALL	1	0USC8K	KCCF140WH	738230
18	caster - no brake	ALL	2	0USD56	KCCF140WH	738230
19	bumper	ALL	2	0USC8F	KCCF140WH	738230
20	discharging water tube	ALL	1	0USC8H	KCCF140WH	738230
21	plug for discharging pipe	ALL	1	0USC8L	KCCF140WH	738230
22	control panel green light element	ALL	1	0USO62	KCCF140WH	738230
23	electronic control panel	< 005222000182	1	0USD58	KCCF140WH	738230
		≥ 005222000182	1	0USO70	KCCF140WH	738230
24	thermostat knob	ALL	1	0USO72	KCCF140WH	738230
25	thermostat	ALL	1	0USD60	KCCF140WH	738230
26	fireproof board	< 005222000182	0	N/A	KCCF140WH	738230
		≥ 005222000182	1	0USO71	KCCF140WH	738230
27	caster with brake	ALL	2	0USD61	KCCF140WH	738230
28	lock cover	ALL	1	0USD66	KCCF140WH	738230
29	door lock and key	ALL	1	0USD62	KCCF140WH	738230

Exploded View Of KCCF140WH

