

**TAVOLO SBARAZZO MANUALE**  
**MANUAL STACKING TABLE**


PNC	MODEL	REF.	Description
865261	HSMSF3LR	a	MANUAL SORTING TABLE, 3 BASKETS, FRONT CONNECTION, LEFT>RIGHT, 1620 MM
865262	HSMSF4LR	b	MANUAL SORTING TABLE, 4 BASKETS, FRONT CONNECTION, LEFT>RIGHT, 2130 MM
865292	HSMSF5LR	c	MANUAL SORTING TABLE, 5 BASKETS, FRONT CONNECTION, LEFT>RIGHT, 2640 MM
865294	HSMSF3RL	a	MANUAL SORTING TABLE, 3 BASKETS, FRONT CONNECTION, RIGHT>LEFT, 1620 MM
865295	HSMSF4RL	b	MANUAL SORTING TABLE, 4 BASKETS, FRONT CONNECTION, RIGHT>LEFT, 2130 MM
865296	HSMSF5RL	c	MANUAL SORTING TABLE, 5 BASKETS, FRONT CONNECTION, RIGHT>LEFT, 2640 MM

Components / Componenti 2-5  
 Spare part lists / liste ricambi 6-7

**BOLD: Last Change/ Grassetto= ultima modifica**

From Ser. Nr. Up to Ser. Nr.	Ed. document publication . 2018 – 05 Ed. page revision 5- 2019 - 06	Page 1	<b>Doc. N° ST11793-60</b>
---------------------------------	------------------------------------------------------------------------	--------	---------------------------

**TAVOLO SBARAZZO MANUALE**  
**MANUAL STACKING TABLE**



<b>Pos</b>	<b>Factory Code</b>	<b>Ref.</b>	<b>Spare Part Code</b>	<b>Descrizione</b>	<b>Description</b>
1	4914854-04	a,b,c		Rullo	Roller
5	ST0 33 90-00	a,b,c			Strainer basket
7	428 02 89-00	a,b,c			Strainer plate Ø114
14	ST0 33 76-00	a,b,c			Foot cpl.
17	ST1 17 72-03	a			Mid Support, Stack Table, 3 Racks
	ST1 17 72-04	b			Mid Support, Stack Table, 4 Racks
	ST1 17 72-05	c			Mid Support, Stack Table, 5 Racks
20	476 84 47-00	a,b,c			Drain connection 1½"
23	ST1 19 14-01	a,b,c			Swivel
25	ST1 18 05-00	a,b,c			Connection Plate
28	ST1 23 98-00	a,b,c			Cover plate
30	ST1 19 22-01	a,b,c			Stand, Stack Table Front Connectn. L>R
34	ST1 20 84-00	a,b,c			Reinforcement, Mid Support, Stack Table
37	ST1 24 02-00	a,b,c			Support, basket (from 01/01/2019)
	ST1 19 11-00	a,b,c			Support, basket (until 31/12/2018)