

Spare Parts List

NO	DESCRIPTION	Serial #	QTY	COMPONENT PNC	Model Number	Model PNC
1	Cabinet	ALL	1	N/A	KCICDC6FH	738372
2	Glass cover Bracket	ALL	2	0USDMH	KCICDC6FH	738373
3	Front LED Light	ALL	3	0USDOY	KCICDC6FH	738374
4	Front Glass	ALL	1	0USDOW	KCICDC6FH	738375
5	Bottom Bracket	ALL	1	0USDOS	KCICDC6FH	738376
6	Middle Bracket	ALL	1	0USDOR	KCICDC6FH	738377
7	Glass	ALL	1	0USDOV	KCICDC6FH	738378
8	Left Cover	ALL	1	0USDMA	KCICDC6FH	738379
9	Left Glass	ALL	1	0USDMK	KCICDC6FH	738380
10	Front Glass Bracket	ALL	2	0USDMP	KCICDC6FH	738381
11	Top Bracket(F)	ALL	1	0USDOP	KCICDC6FH	738382
11a	Top Bracket(R)	ALL	1	0USDOQ	KCICDC6FH	738383
12	Glass Back Door	ALL	2	0USDOX	KCICDC6FH	738384
13	Right Glass	ALL	1	0USDML	KCICDC6FH	738385
14	Gasket/Grip	< 004342000182	4	0USX04	KCICDC6FH	738386
		≥ 004342000182	4	0USO60	KCICDC6FH	738387
15	Glass Clamp 2	ALL	4	0USDOZ	KCICDC6FH	738388
16	Back Door	ALL	1	0USDL2	KCICDC6FH	738389
16a	Back Door Gasket	ALL	1	0USO43	KCICDC6FH	738390
16b	Back Door Hinge	ALL	1	0USO44	KCICDC6FH	738391
16c	Back Door Latch	ALL	1	0USO45	KCICDC6FH	738392
17	Right Cover	ALL	1	0USDMB	KCICDC6FH	738393
18	Plug	ALL	1	0USDQJ	KCICDC6FH	738394
19	Shelf Components	ALL	1	N/A	KCICDC6FH	738395
19a1	Tub Bracket 1 - Front/Back	ALL	2	0USD0H	KCICDC6FH	738396
19a2	10.16" Lower Tub Bracket Insert for Standard Tub	< 004342000182	0	N/A	KCICDC6FH	738397
		≥ 004342000182	6	0USX05	KCICDC6FH	738398
19a2-1	Bracket Rubber Grip	ALL	24	0USFB1	KCICDC6FH	738399
19a3	Tub Bracket Panel (Lower brackets welded to panel)	< 004342000182	1	0USDOK	KCICDC6FH	738400
	Tub Bracket Panel (with slits for removable brackets)	≥ 004342000182	1	0USX07	KCICDC6FH	738401
19a4	8.25" Lower Tub Bracket Insert for Ropak Tub	< 004342000182	0	N/A	KCICDC6FH	738402
		≥ 004342000182	6	0USFB5	KCICDC6FH	738403
19a4-1	Bracket Rubber Grip	ALL	24	0USFB1	KCICDC6FH	738404
19a5	Tub Cover Bracket 1 - Front/Back	ALL	2	0USD0G	KCICDC6FH	738405
19a6	Tub Cover Bracket 2	ALL	1	0USD0I	KCICDC6FH	738406
19a7	Tub Cover	ALL	1	0USD0J	KCICDC6FH	738407
20	Back Platform	ALL	1	0USD0T	KCICDC6FH	738408
21	Back Door Guide	ALL	1	0USD0U	KCICDC6FH	738409
22	Back Platform Bracket	ALL	3	0USDMG	KCICDC6FH	738410
23	Lower Glass Lid	ALL	1	0USD0O	KCICDC6FH	738411
24	Lock and Key	ALL	1	0USDMV	KCICDC6FH	738412
25	Upper Glass Lid	ALL	1	0USD0N	KCICDC6FH	738413
26	Inner Cabinet LED Light	ALL	1	0USDQL	KCICDC6FH	738414
27	Screw Cover	ALL	10	0USDMJ	KCICDC6FH	738415
28	Rear Cover	ALL	1	0USDKP	KCICDC6FH	738416
29	Control Bracket	ALL	1	0USD0L	KCICDC6FH	738417
30	Control Panel	ALL	1	0USD07	KCICDC6FH	738419
31	Digital Thermostat	ALL	1	0USDQI	KCICDC6FH	738421
32	Switch	ALL	1	0USD86	KCICDC6FH	738422
33	Frost Removal - Ice scraper	ALL	1	0USDMQ	KCICDC6FH	738424
34	Filter Dryer	< 003162000182	1	0USD78	KCICDC6FH	738425
		≥ 003162000182	1	0USO59	KCICDC6FH	738426
35	external condenser	ALL	1	0USDL4	KCICDC6FH	738427

36	Cover	ALL	1	0USDKS	KCICDC6FH	738428
37	Fan	ALL	1	0USD69	KCICDC6FH	738429
37a	Fan Blade	ALL	1	0USDQO	KCICDC6FH	738430
38	Fan Bracket	< 004342000182	1	0USD70	KCICDC6FH	738431
		≥ 004342000182	1	0USO65	KCICDC6FH	738432
39	Power Cord	ALL	1	0USDL8	KCICDC6FH	738433
40	Compressor	ALL	1	0USDQR	KCICDC6FH	738434
40a	Relay	ALL	1	0USDR1	KCICDC6FH	738435
40b	Overload	ALL	1	0USDQZ	KCICDC6FH	738436
40c	Start Capacitor	ALL	1	0USDR0	KCICDC6FH	738437
40d	Run Capacitor	ALL	1	0USDR2	KCICDC6FH	738438
41	Control Connection Wire	ALL	1	0USDL5	KCICDC6FH	738439
42	Transformer (Inner Cabinet and Front LED)	ALL	1	0USDMR	KCICDC6FH	738441
43	Transformer - FRONT LED	ALL	0	N/A	KCICDC6FH	738443
44	Castor without Brake	ALL	2	0USDKQ	KCICDC6FH	738445
45	Water Collector	ALL	1	0USDKO	KCICDC6FH	738446
46	Dipping Well Mounting Screw	ALL	0	N/A	KCICDC6FH	738447
47	Castor with Brake	ALL	2	0USDKR	KCICDC6FH	738449
48	Load Boundaries	ALL	1	0USDKN	KCICDC6FH	738450

