

Spare Parts List

Model: KCICDC6FH
PNC: 738372
REV: 3/19/2025

NO	DESCRIPTION	Serial #	QTY	COMPONENT PNC	Model Number	Model PNC
1	Cabinet	ALL	1	N/A	KCICDC6FH	738372
2	Glass cover Bracket	ALL	2	0USDMH	KCICDC6FH	738372
3	Front LED Light	ALL	3	0USDOY	KCICDC6FH	738372
4	Front Glass	ALL	1	0USDOW	KCICDC6FH	738372
5	Bottom Bracket	ALL	1	0USDOS	KCICDC6FH	738372
6	Middle Bracket	ALL	1	0USDOR	KCICDC6FH	738372
7	Glass	ALL	1	0USDOV	KCICDC6FH	738372
8	Left Cover	ALL	1	0USDMA	KCICDC6FH	738372
9	Left Glass	ALL	1	0USDMK	KCICDC6FH	738372
10	Front Glass Bracket	ALL	2	0USDMP	KCICDC6FH	738372
11	Top Bracket(F)	ALL	1	0USDOP	KCICDC6FH	738372
11a	Top Bracket(R)	ALL	1	0USDOQ	KCICDC6FH	738372
12	Glass Back Door	ALL	2	0USDOX	KCICDC6FH	738372
13	Right Glass	ALL	1	0USDML	KCICDC6FH	738372
14	Gasket/Grip	< 004342000182	4	0USX04	KCICDC6FH	738372
		≥ 004342000182	4	0USO60	KCICDC6FH	738372
15	Glass Clamp 2	ALL	4	0USDOZ	KCICDC6FH	738372
16	Back Door	ALL	1	0USDL2	KCICDC6FH	738372
16a	Back Door Gasket	ALL	1	0USO43	KCICDC6FH	738372
16b	Back Door Hinge	ALL	1	0USO44	KCICDC6FH	738372
16c	Back Door Latch	ALL	1	0USO45	KCICDC6FH	738372
17	Right Cover	ALL	1	0USDMB	KCICDC6FH	738372
18	Plug	ALL	1	0USDQJ	KCICDC6FH	738372
19	Shelf Components	ALL	1	N/A	KCICDC6FH	738372
19a1	Tub Bracket 1 - Front/Back	ALL	2	0USD0H	KCICDC6FH	738372
19a2	10.16" Lower Tub Bracket Insert for Standard Tub	< 004342000182	0	N/A	KCICDC6FH	738372
		≥ 004342000182	6	0USX05	KCICDC6FH	738372
19a2-1	Bracket Rubber Grip	ALL	24	0USFB1	KCICDC6FH	738372
19a3	Tub Bracket Panel (Lower brackets welded to panel) Tub Bracket Panel (with slits for removable brackets)	< 004342000182	1	0USDOK	KCICDC6FH	738372
		≥ 004342000182	1	0USX07	KCICDC6FH	738372
19a4	8.25" Lower Tub Bracket Insert for Ropak Tub	< 004342000182	0	N/A	KCICDC6FH	738372
		≥ 004342000182	6	0USFB5	KCICDC6FH	738372
19a4-1	Bracket Rubber Grip	ALL	24	0USFB1	KCICDC6FH	738372
19a5	Tub Cover Bracket 1 - Front/Back	ALL	2	0USD0G	KCICDC6FH	738372
19a6	Tub Cover Bracket 2	ALL	1	0USD0I	KCICDC6FH	738372
19a7	Tub Cover	ALL	1	0USD0J	KCICDC6FH	738372
20	Back Platform	ALL	1	0USD0T	KCICDC6FH	738372
21	Back Door Guide	ALL	1	0USD0U	KCICDC6FH	738372
22	Back Platform Bracket	ALL	3	0USDMG	KCICDC6FH	738372
23	Lower Glass Lid	ALL	1	0USD0O	KCICDC6FH	738372
24	Lock and Key	ALL	1	0USDMV	KCICDC6FH	738372
25	Upper Glass Lid	ALL	1	0USD0N	KCICDC6FH	738372
26	Inner Cabinet LED Light	ALL	1	0USDQL	KCICDC6FH	738372
27	Screw Cover	ALL	10	0USDMJ	KCICDC6FH	738372
28	Rear Cover	ALL	1	0USDKP	KCICDC6FH	738372
29	Control Bracket	ALL	1	0USD0L	KCICDC6FH	738372
30	Control Panel	ALL	1	0USD07	KCICDC6FH	738372
31	Digital Thermostat	ALL	1	0USDQI	KCICDC6FH	738372
32	Switch	ALL	1	0USD86	KCICDC6FH	738372
33	Frost Removal - Ice scraper	ALL	1	0USDMQ	KCICDC6FH	738372
34	Filter Dryer	< 003162000182	1	0USD78	KCICDC6FH	738372
		≥ 003162000182	1	0USO59	KCICDC6FH	738372
35	external condenser	ALL	1	0USDL4	KCICDC6FH	738372

36	Cover	ALL	1	0USDKS	KCICDC6FH	738372
37	Fan	ALL	1	0USD69	KCICDC6FH	738372
37a	Fan Blade	ALL	1	0USDQO	KCICDC6FH	738372
38	Fan Bracket	< 004342000182	1	0USD70	KCICDC6FH	738372
		≥ 004342000182	1	0USO65	KCICDC6FH	738372
39	Power Cord	ALL	1	0USDL8	KCICDC6FH	738372
40	Compressor	ALL	1	0USDQR	KCICDC6FH	738372
40a	Relay	ALL	1	0USDR1	KCICDC6FH	738372
40b	Overload	ALL	1	0USDQZ	KCICDC6FH	738372
40c	Start Capacitor	ALL	1	0USDR0	KCICDC6FH	738372
40d	Run Capacitor	ALL	1	0USDR2	KCICDC6FH	738372
41	Control Connection Wire	ALL	1	0USDL5	KCICDC6FH	738372
42	Transformer (Inner Cabinet and Front LED)	ALL	1	0USDMR	KCICDC6FH	738372
43	Transformer - FRONT LED	ALL	0	N/A	KCICDC6FH	738372
44	Castor without Brake	ALL	2	0USDKQ	KCICDC6FH	738372
45	Water Collector	ALL	1	0USDKO	KCICDC6FH	738372
46	Dipping Well Mounting Screw	ALL	0	N/A	KCICDC6FH	738372
47	Castor with Brake	ALL	2	0USDKR	KCICDC6FH	738372
48	Load Boundaries	ALL	1	0USDKN	KCICDC6FH	738372

Exploded View Of KCICDC6FH

