


PNC	Model	Ref	Page	Notes
283011	E0UUCEBOMOH	a	2 - 3	ELECTROLUX
283018	Z0UUCEBOMOH	b	2 - 3	ZANUSSI
283025	N0UUCEBOMOH	c	2 - 3	TO BRAND
283012	E0UUCDBOMOH	d	2 - 4	ELECTROLUX
283019	Z0UUCDBOMOH	e	2 - 4	ZANUSSI
283026	N0UUCDBOMOH	f	2 - 4	TO BRAND



EL.SALAMANDER, ULTRA RAPID, OPEN 3-SIDES, 600 MM
SALAMANDRA EL., ULTRA RAPIDA, APERTA 3 LATI, 600 MM

Pos.	Cod.ric. Part No.	Factory Code	Descrizione	Description	v	w	t	c	Note/Notes
1	0C6823	-	Tappo per maniglia electrolux	Plug for handle electrolux				x	a, d
2	0CB602	RC02634000	Distanziale maniglia	Spacer handle					b, c, e, f
3	0CB603	RC01784000	Maniglia Zanussi - To Brand	Handle Zanussi - To Brand		x			b, c, e, f
	095206	0835R12503	Maniglia Electrolux	Handle Electrolux		x			a, d
4	0CB613	RC02712000	Membrana Electrolux	Layer Electrolux		x			a, d
	0CB614	RC02713000	Membrana Zanussi	Layer Zanussi		x			b, e
	0CB615	RC02714000	Membrana to brand	Layer to brand		x			c, f
5	0CB605	RC01028000	Gruppo comando qse	Qse command group	x				
6	0C8700	-	Manopola Electrolux	Knob Electrolux					a, d
	0CB616	RC01941000	Manopola Zanussi - to brand	Knob Zanussi - brand					b, c, e, f
7	0CB607	RC01783000	Portalampada trasparente d10	Transparent lampholder d10				x	
8	0CB608	RC01782000	Lampada verde 230V	Lamp green 230V		x			
9	006940	RC01015000	Scheda elettronica qse60	Electronic board qse60	x				
10	0CB609	RC01027000	Impugnatura	Handle					
11	0CB610	RC01229000	Resistenza elettrica qse60 4kW	Heating element qse60 4kW	x				
12	0CB611	RC00166000	Microinterruttore	microswitch	x				
13	002750	-	Fusibile 5X20 0.4A(T) 250V	Fuse 5X20 0.4A(T) 250V			x		