

Spare Parts List

NO	DESCRIPTION	Serial #	QTY	COMPONENT PNC	Model Number	Model PNC
1	TOP	ALL	1PC	0USM16	KCHBB72S	738271
2	TOP FIXED CLIP	ALL	4PCS	0USL81	KCHBB72S	738271
3	BODY	ALL	1PC	N/A	KCHBB72S	738271
4	SUPPORT OF BODY	ALL	1PC	0USL54	KCHBB72S	738271
4a	BRAKE WHEEL	ALL	3PCS	0USF04	KCHBB72S	738271
4b	NORMAL WHEEL	ALL	3PCS	0USH64	KCHBB72S	738271
4c	Castor Mounting Bolt (4-PACK)	ALL	6PCS	0USC2T	KCHBB72S	738271
4d	Castor Mounting Locking Washer (4-PACK)	ALL	6PCS	0USC2Z	KCHBB72S	738271
4e	Castor Mounting Flat Washer (4-PACK)	ALL	6PCS	0USC2Y	KCHBB72S	738271
6	SHELF SUPPORT	ALL	12PCS	0USI65	KCHBB72S	738271
6a	Shelf Support Screw	ALL	60PCS	0USM14	KCHBB72S	738271
7	SHELF L	ALL	2PCS	0USN12	KCHBB72S	738271
7a	SHELF R	ALL	2PCS	0USN13	KCHBB72S	738271
7b	SHELF MIDDLE	ALL	2PCS	0USCOH	KCHBB72S	738271
8	K SHAPE CLIP	ALL	24PCS	0USH19	KCHBB72S	738271
9	DOOR SPRING HINGE RIGHT	ALL	2PCS	0USF83	KCHBB72S	738271
9a	DOOR SPRING HINGE LEFT	ALL	1PC	0USJ44	KCHBB72S	738271
10	DOOR HINGE/DOWN	ALL	3PCS	0USI63	KCHBB72S	738271
11	DOOR/LEFT	ALL	1PC	0USJ07	KCHBB72S	738271
11a	DOOR/RIGHT	ALL	2PCS	0USJ08	KCHBB72S	738271
12	GASKET	ALL	3PCS	0USI72	KCHBB72S	738271
13	LOCK HOOK	ALL	3PCS	0USJ20	KCHBB72S	738271
14	FRONT PANEL	ALL	1PC	0USJ23	KCHBB72S	738271
14a	Thermostat Protector Cover	ALL	1PC	0USCOB	KCHBB72S	738271
14b	Thermostat Protector Screw (Black)	ALL	1PC	0USCOA	KCHBB72S	738271
15	Thermostat - Full Set	ALL	1PC	0USDAC	KCHBB72S	738271
15a	Thermostat Contactor	ALL	1PC	0USI49	KCHBB72S	738271
15b	Thermostat Display	ALL	1PC	0USM12	KCHBB72S	738271
15c	Thermostat Components	ALL	1PC	0USLO3	KCHBB72S	738271
15d	Inner Chest Temperature Sensor Probe	ALL	1PC	0USC4B	KCHBB72S	738271
16	ELECTRICAL EQUIPMENT FIXER	ALL	1PC	0USK39	KCHBB72S	738271
17	LED POWER SUPPLY	ALL	1PC	0USH38	KCHBB72S	738271
19	UPPER HINGE AXIS JACKET	ALL	3PCS	0USI67	KCHBB72S	738271
20	DOOR HINGE/UP/LEFT	ALL	1PC	0USI62	KCHBB72S	738271
20a	DOOR HINGE/UP/RIGHT	ALL	2PCS	0USL91	KCHBB72S	738271
21	CAPILLARY	ALL	1PC	0USM13	KCHBB72S	738271
22	CONDENSER	ALL	1PC	0USI91	KCHBB72S	738271
23	CONDENSER FAN	ALL	1PC	0USI51	KCHBB72S	738271
24	DRIER SUPPORT	ALL	1PC	0USI78	KCHBB72S	738271

25	FILTER DRIER	ALL	1PC	0USG66	KCHBB72S	738271
26	UNIT ROOM COVER	ALL	1PC	0USJ22	KCHBB72S	738271
27	UNIT ROOM COVER FIXER	ALL	1PC	0USK40	KCHBB72S	738271
28	DISCHARGE PIPE	ALL	1PC	0USI95	KCHBB72S	738271
29	WATER BOX	ALL	1PC	0USI48	KCHBB72S	738271
30	SUCTION PIPE	ALL	1PC	0USI93	KCHBB72S	738271
31	COMPRESSOR	ALL	1PC	0USF32	KCHBB72S	738271
31a	COMPRESSOR ELECTRICAL COMPONENT SET	ALL	1PC	0USDF8	KCHBB72S	738271
32	UNIT ROOM GRILL	ALL	1PC	0USI83	KCHBB72S	738271
32a	LOCATION KNOB	ALL	2PCS	0USH46	KCHBB72S	738271
33	PLUG	ALL	1PC	0USI53	KCHBB72S	738271
34	EVAPORATOR	ALL	1PC	0USJ16	KCHBB72S	738271
34a	Evaporator Temperature Sensor Probe	ALL	1PC	0USC6Q	KCHBB72S	738271
35	FAN SUPPORT	ALL	1PC	0USK43	KCHBB72S	738271
36	EVAPORATOR FAN BLADE	ALL	1PC	0USI52	KCHBB72S	738271
37	EVAPORATOR FAN GRILL	ALL	1PC	0USI25	KCHBB72S	738271
38	EVAPORATOR FAN MOTOR	ALL	1PC	0USF16	KCHBB72S	738271
39	EVAPORATOR COVER	ALL	1PC	0USJ24	KCHBB72S	738271
41	SENSOR FIXED CLIP	ALL	1PC	0USM10	KCHBB72S	738271
42	DOOR SWITCH BOX	ALL	3PCS	0USF88	KCHBB72S	738271
43	DOOR SWITCH	ALL	3PCS	0USI59	KCHBB72S	738271
44	UNIT BOARD	ALL	1PC	0USK42	KCHBB72S	738271
45	EVAPORATOR WATER PAN	ALL	1PC	0USJ21	KCHBB72S	738271
46	AIR FLOW CONDUCT BOARD	ALL	1PC	0USJ65	KCHBB72S	738271
47	LAMP	ALL	1PC	0USI57	KCHBB72S	738271

