


Spare Parts List

NO	DESCRIPTION	Serial #	QTY	COMPONENT PNC	Model Number	Model PNC
1	TOP	ALL	1PC	0USM16	KCHBB72G	738274
2	TOP FIXED CLIP	ALL	4PCS	0USL81	KCHBB72G	738274
3	BODY	ALL	1PC	N/A	KCHBB72G	738274
4	SUPPORT OF BODY	ALL	1PC	0USL54	KCHBB72G	738274
4a	BRAKE WHEEL	ALL	3PCS	0USF04	KCHBB72G	738274
4b	NORMAL WHEEL	ALL	3PCS	0USH64	KCHBB72G	738274
4c	Castor Mounting Bolt (4-PACK)	ALL	6PCS	0USC2T	KCHBB72G	738274
4d	Castor Mounting Locking Washer (4-PACK)	ALL	6PCS	0USC2Z	KCHBB72G	738274
4e	Castor Mounting Flat Washer (4-PACK)	ALL	6PCS	0USC2Y	KCHBB72G	738274
6	SHELF SUPPORT	ALL	12PCS	0USI65	KCHBB72G	738274
6a	Shelf Support Screw	ALL	60PCS	0USM14	KCHBB72G	738274
7	SHELF L	ALL	2PCS	0USN12	KCHBB72G	738274
7a	SHELF R	ALL	2PCS	0USN13	KCHBB72G	738274
7b	SHELF (middle)	ALL	2PCS	0USCOH	KCHBB72G	738274
8	K SHAPE CLIP	ALL	24PCS	0USH19	KCHBB72G	738274
9	DOOR SPRING HINGE RIGHT	ALL	2PCS	0USF83	KCHBB72G	738274
9a	DOOR SPRING HINGE LEFT	ALL	1PC	0USJ44	KCHBB72G	738274
10	DOOR HINGE/DOWN	ALL	3PCS	0USI63	KCHBB72G	738274
11	GLASS DOOR/LEFT	ALL	1PC	0USI87	KCHBB72G	738274
11a	GLASS DOOR/RIGHT	ALL	2PCS	0USI89	KCHBB72G	738274
12	GASKET	ALL	3PCS	0USI75	KCHBB72G	738274
13	LOCK HOOK	ALL	3PCS	0USJ20	KCHBB72G	738274
14	FRONT PANEL	ALL	1PC	0USJ23	KCHBB72G	738274
14a	Thermostat Protector Cover	ALL	1PC	0USCOB	KCHBB72G	738274
14b	Thermostat Protector Screw (Black)	ALL	1PC	0USCOA	KCHBB72G	738274
15	Thermostat - Full Set	ALL	1PC	0USDAC	KCHBB72G	738274
15a	Thermostat Contactor	ALL	1PC	0USI49	KCHBB72G	738274
15b	Thermostat Display	ALL	1PC	0USM12	KCHBB72G	738274
15c	Thermostat Components	ALL	1PC	0USLO3	KCHBB72G	738274
15d	Inner Chest Temperature Sensor Probe	ALL	1PC	0USC4B	KCHBB72G	738274
16	ELECTRICAL EQUIPMENT FIXER	ALL	1PC	0USK39	KCHBB72G	738274
17	LED POWER SUPPLY	ALL	1PC	0USH38	KCHBB72G	738274
19	UPPER HINGE AXIS JACKET	ALL	3PCS	0USI67	KCHBB72G	738274
20	DOOR HINGE/UP/LEFT	ALL	1PCS	0USI64	KCHBB72G	738274
20a	DOOR HINGE/UP/RIGHT	ALL	2PCS	0USM18	KCHBB72G	738274
21	CAPILLARY	ALL	1PC	0USM13	KCHBB72G	738274
22	CONDENSER	ALL	1PC	0USI91	KCHBB72G	738274
23	CONDENSER FAN	ALL	1PC	0USI51	KCHBB72G	738274
24	DRIER SUPPORT	ALL	1PC	0USI78	KCHBB72G	738274

25	FILTER DRIER	ALL	1PC	0USG66	KCHBB72G	738274
26	UNIT ROOM COVER	ALL	1PC	0USJ22	KCHBB72G	738274
27	UNIT ROOM COVER FIXER	ALL	1PC	0USK40	KCHBB72G	738274
28	DISCHARGE PIPE	ALL	1PC	0USI95	KCHBB72G	738274
29	WATER BOX	ALL	1PC	0USI48	KCHBB72G	738274
30	SUCTION PIPE	ALL	1PC	0USI93	KCHBB72G	738274
31	COMPRESSOR	ALL	1PC	0USF32	KCHBB72G	738274
31a	COMPRESSOR ELECTRICAL COMPONENT SET	ALL	1PC	0USDF8	KCHBB72G	738274
32	UNIT ROOM GRILL	ALL	1PC	0USI83	KCHBB72G	738274
32a	LOCATION KNOB	ALL	2PCS	0USH46	KCHBB72G	738274
33	PLUG	ALL	1PC	0USI53	KCHBB72G	738274
34	EVAPORATOR	ALL	1PC	0USJ16	KCHBB72G	738274
34a	Evaporator Temperature Sensor Probe	ALL	1PC	0USC6Q	KCHBB72G	738274
35	FAN SUPPORT	ALL	1PC	0USK43	KCHBB72G	738274
36	EVAPORATOR FAN BLADE	ALL	1PC	0USI52	KCHBB72G	738274
37	EVAPORATOR FAN GRILL	ALL	1PC	0USI25	KCHBB72G	738274
38	EVAPORATOR FAN MOTOR	ALL	1PC	0USF16	KCHBB72G	738274
39	EVAPORATOR COVER	ALL	1PC	0USJ24	KCHBB72G	738274
41	SENSOR FIXED CLIP	ALL	1PC	0USM10	KCHBB72G	738274
42	DOOR SWITCH BOX	ALL	3PCS	0USF88	KCHBB72G	738274
43	DOOR SWITCH	ALL	3PCS	0USF85	KCHBB72G	738274
44	UNIT BOARD	ALL	1PC	0USK42	KCHBB72G	738274
45	EVAPORATOR WATER PAN	ALL	1PC	0USJ21	KCHBB72G	738274
46	AIR FLOW CONDUCT BOARD	ALL	1PC	0USJ65	KCHBB72G	738274
47	LAMP	ALL	1PC	0USI57	KCHBB72G	738274
48	LIGHT SWITCH	ALL	1PC	0USH45	KCHBB72G	738274



EXPLODE DRAWING OF KCHBB72G