



922718

Pos n°	Cod. Electrolux P.	
1	RR000S2454	
2	RR000S2465	
3	RR000CB941	
4	RR000CB940	
5	RR000S2749	
6	RR000S2790	
7	RR000CB943	
8	RR000S2753	



922718

Pos n°	Cod. Electrolux P.	
9	RR000S2752	
10	RR000CB945	
11	RR000S2756	
12	RR000S2757	



922718

Pos n°	Cod. Electrolux P.	
13	RR000S2749	
14	RR000S2750	
15	RR000S2751	
16	RR000TTMB1	
17	RR000S2466	